
100
CODEC
SPEECH CODEC
4
CHANNEL CODEC
CHANNEL CODER
42
44
6
2
46
8
48
10
50
52
TRANSMISSION CODEC MODE BLOCK
12
68
70
CONTROL CIRCUIT
26
38
26
32
CODEC MODE SELECTOR
34
36
72
44
30
DETECTION
28
MONITOR
42
RECEIVE CODEC MODE BLOCK
20
56
66
16
60
18
14
62
22
24
64
58
CODEC
SPEECH CODEC
CHANNEL CODEC
CHANNEL DECODER
40

FIG. 1

1/1